
VOX AC30 TREBLE & BASS Circuit Diagram
BRIGHT INPUTS
NORMAL INPUTS
VIB/TREM INPUTS
ECC83
EL84
EZ81
115V
OPST Mains ON/OFF SWITCH
FUSE
TREBLE
BASS
DEPTH PHASE
TREM SPEED
FOOT SWITCH